



Meter readings For Models MF222 to MF752, MF254 to MF364, MF227 to MF287

Please Press Menu



Click Counter button as shown below



Meter readings For Models MF222 to MF752, MF254 to MF364, MF227 to MF287

The Machines meter reading is on the left hand side of the screen as shown below

